



Purpose

To provide instructions for connecting modified battery set to the Bird Model 4311 Thruline® Wattmeter.

- 1. Remove four screws securing the back panel.
- Separate back panel without disconnecting battery leads, placing it flat on the work surface. Note where the battery leads connect to the PC board.
- Remove the black lead from the old unit and replace with the black lead from the new unit.
- 4. Remove the red lead from the old unit and replace with the red lead from the new unit.
- 5. Remove the gray lead from the old unit and replace with the red/black twisted pair from the new unit.
- 6. Secure the new back with the four screws removed in step one. Be careful not to pinch new battery leads in back cover.

NOTE: The new batteries (Bird P/N 5A2273) are AA size 3.6V. Do not use standard AA batteries in this unit.

